

**Specification for the 3 Manual- 12 Rank Theatre Pipe Organ
located in
The Paramount Theatre
Anderson, Indiana**

Pedal	Accompaniment	Great	Solo
32' Accoustic Bass	8' English Posthorn	16' English Posthorn TC	16' English Posthorn TC
16' Tuba	8' Trumpet	16' Trumpet TC	16' Trumpet TC
16' Sousa -phone	8' Tuba	16' Tuba	16' Tuba
16' Tibia	8' Horn Diapason	16' Sousa-phone	16' Sousa-phone
16' Bourdon	8' Tibia Clausa	16' Tibia Clausa TC	16' Tibia Clausa TC
8' English Posthorn	8' Clarinet	16' Kinura TC	16' Orchestral Oboe TC
8' Trumpet	8' Viol D'Orchest.	16' Orchest'I Oboe TC	16' Clarinet TC
8' Tuba	8' Viol Celeste	16' Clarinet TC	16' Viol D'Orchest. 2 RKS. TC
8' Horn Diapason	8' Clarabella Flute	16' Viol D'Orchest. 2 RKS. TC	16' Bass Flute
8' Tibia	8' Vox Humana	16' Bass Flute	16' Vox Humana TC
8' Clarinet	4' Octave	16' Vox Humana TC	8' English Posthorn
8' Cello 2RKS.	4' Tibia Clausa	8' English Posthorn	8' Trumpet
8' Bass Flute	4' Violina	8' Trumpet	8' Tuba
16' Piano -Forte	4' Celeste	8' Tuba	8' Horn Diapason
8' Piano -Forte	4' Flute	8' Horn Diapason	8' Tibia Clausa
Bass Drum Orchest'l	4' Vox Humana	8' Tibia Clausa	8' Kinura
Kettle Drum	2 2/3' Nazard	8' Kinura	8' Orchest'I Oboe
Crash Cymbal	2' Flagolet	8' Orchest'I Oboe	8' Clarinet
Cymbal	8' Pianoforte	8' Clarinet	8' Viol D'Orchest. 2 RKS.
Jazz Cymbal	Harp Sub	8' Viol D'Orchest. 2 RKS.	8' Clarabella Flute
Triangle	Harp	8' Clarabella Flute	8' Vox Humana
Accomp to Pedal Traps	Chryso-glott Sub	8' Vox Humana	4' Octave
8' Accomp to Pedal	Chryso-glott	5 1/3' Tibia Fifth	4' Tibia Clausa
8' Great to Pedal	Snare Drum	4' Octave	4' Violina 2 RKS.
4' Great to Pedal	Tom Tom	4' Tibia Clausa	4' Flute
8' Solo to Pedal	Tambourine	4' Violina 2 RKS.	4' Vox Humana
	Castanets	4' Flute	2 2/3' Tibia Twelfth
	Wood Block	4' Vox Humana	2' Tibia Piccolo
	Jazz Drum	3 1/5' Tibia Tenth	2' String Fifteenth
	Shuffle Drum	2 2/3' Tibia Twelfth	2' Flagolet
	Cymbal	2 2/3' Nazard	1 3/5' Tibia Tiercena
	Jazz Cymbal	2' Tibia Piccolo	1 1/3' Tibia Larigot
	Sleighbells	2' String Fifteenth	8' Piano-forte
	4' Accomp to Accomp	2' Flagolet	Harp Sub
	8' Solo to Accomp	1 3/5' Tibia Tiercena	Harp
		1 3/5' Tiercena	Chryso-glott Sub
	Accomp 2nd Touch (Backrail)	1' Fife	Chryso-glott
		16' Piano-forte	Xylophone Sub
	8' English Posthorn	8' Piano-forte	Xylophone
	8' Trumpet	4' Piano-forte	Glocken-spiel
	8' Tuba	Harp Sub	Cathedral Chimes
	8' Horn Diapason	Harp	16' Solo to Solo
	8' Tibia Clausa	Chryso-glott Sub	4' Solo to Solo
	8' Clarinet	Xylophone Sub	3rd Solo Major Third
	4' Tibia Clausa	Xylophone	5th Solo Major Fifth
	8' Piano	Glocken-spiel	7th Solo Dominant Seventh
	Harp Sub	16' Great to Great	
	Chryso-glott	8' Great Unison Off	Tremulants (Backrail)
	Octave Glockenspiel	4' Great to Great	Main (Diapason, Clarinet, F
	Cathedral Chimes	8' Solo to Great	Strings (VDO, VDO Celeste
	Accomp Traps	8' Solo to Great PIZZ.	Solo (Trumpet, Kinura, O. C
	4' Great to Accomp	16' Posthorn PIZZ.	Tibia
	8' Solo to Accomp		Vox Humana
			Tuba
			Vibraphone
			General (Backrail)
			Piano Sustain On
			Great Sost. Off
			Celeste Off
			Harp Reit.
			Xylophone Reit.
			Glocken-spiel Reit.
			Range (norm. locked out)

**Specification for the 3 Manual- 12 Rank Theatre Pipe Organ
located in
The Paramount Theatre
Anderson, Indiana**

COMBINATION PISTONS:

Solo Manual:	Generals 11- 15 / Solo	Divisionals 1- 10 / Generals 16 - 20
Great Manual:	Generals 6- 10 / Great	Divisionals 1- 15
Accomp. Manual:	Set / Generals 1- 5 /	Accomp. Divisionals 1- 10 / Gen. Cancel & Pedal Divisionals 1- 10

BUTTON CONTROLS:

Accomp. Key Cheek: (left)	Transposer: Up, Unison, Down	(right)	Door Bell
Great Key Cheek: (left)	Wood Block	(right)	Train Whistle Bird Whistle
Solo Key Cheek: (left)	Operator		

TOE STUDS:

(left)	Siren Klaxon Fire Gong Railroad Bell Surf and Wave Comedy Whistle	(right)	Kettle Drum Crash (Bass Drum & Crash Cymbal) Chinese Gong Roll Chinese Gong Pedal Chime
--------	----------------------------------------------------------------------------------	---------	-----------------------------------------------------------------------------------------------------

**Specification for the 3 Manual- 12 Rank theatre Pipe Organ
located in
The Paramount Theatre
Anderson, Indiana**

CHAMBER & MAJOR COMPONENTS

MAIN CHAMBER:

16'	Concert Flute	101 notes
16'	Diapason (Sousaphone)	85 notes
16'	Tuba	73 notes
8'	Clarinet	61 notes
8'	Viol d' Orchestra	85 notes
8'	Viol Celeste	61 notes
	Chrysoglott/ Vibraphone	49 notes (exposed above main chamber)
	Marimba Harp (MIDI)	49 notes
	Piano	85 notes (7' Yamaha Grand piano on stage)

Toy Counters: A) Bass Drum, Chinese Gong, Gong Roll, Triangle, Tap Cymbal, Crash Cymbal
B) Snare drum, Jazz Drum, Shuffle Drum, Tambourine, Castanets,
Chinese Tom-Tom, Wood Block, Fire Gong, Train Whistle, Jazz Cymbal.

SOLO CHAMBER:

16'	Tibia Clausa	97 notes
8'	Vox Humana	73 notes
8'	Kinura	61 notes (Original rank, large scale loud Krumet)
8'	Orchestral Oboe	61 notes (Trivo)
8'	Trumpet	61 notes (Trivo, flared bell)
8'	Post Horn	61 pipes (Trivo)
	Xylophone	37 notes
	Glockenspiel	30 notes
	Chimes	13 notes

Toy Counter: Surf and Wave, Door Bell, Acme Siren, Siren, Klaxon Horn, Sleighbells, Bird Whistle

RELAY AND COMBINATION SYSTEM

Rickman Uniflex switching system

BLOWER

Spencer 10 hp Orgablo